

Knowledgebase > Products > REQUIRED PASSWORD CHANGE > Which devices are subject to the Required Password Change?

Which devices are subject to the Required Password Change? Christoph Strauss - 2019-11-05 - REQUIRED PASSWORD CHANGE

Routers: DX40, DX940, DX940e, 10XTS, 10RX, 5RX

Managed Switches: 6K8, 6KL, 6KM, 6KQ, 6KQE, 6K16(V), 6K25(e), 6K32, 10KT, 10KG, 12KX